# Kneeboard Rack

**INSTALLATION MANUAL** 



### **Gather Additional Tools and Materials**

Allen Wrench Set




Loctite® 242 Blue




### Step 1: Attaching Clamp to Tower


Clamp the mounting bracket to the desired spot on the tower leg. Mount to a verticle or semi-verticle portion of the tower. DO NOT MOUNT TO HORIZONTAL PIPE.



Choose the appropriate sized insert for your tower. A slight gap will show between the inserts.



Attach the clamp and inserts to the desired location.



PRO TIP: We recommend to torque the clamp screws to 22ft/lbs to ensure an even tension.


\*Loctite® 242 Blue can be applied to any bolt during assembly to ensure a locking fit.




Do you have questions? Call us @ 877.777.8693 Monday - Friday, 8am-5pm EST

# Step 2: Connecting Rack to Clamp


1. Attach the rack to the mounting bracket.




3. Tighten down the quick-release nut.



2. Check the quick-release set screw and tighten it down.




4. Close the quick-release lever to ensure that the rack will not slide off.



# Step 3: Adjusting Rack Postion

1. Rotate the rack to be level with floor of the boat.



2. Tighten down the set screws to keep the rack from freely rotating.

